OWNERS MANUAL




TABLE OF CONTENTS

• Important Safeguards	2
Parts Description	4
Operation Guidelines	5
Cleaning and Storage	6
• Warranty	7
Basic Information / Special Features	9

IMPORTANT SAFEGUARDS

When using your Apollo Personal Blender, basic safety precautions should always be followed, including the following:

- **1.** Read all instructions before use.
- **2.** Close supervision is necessary when any appliance is used by or near children.
- **3.** Avoid contact with moving parts.
- 4. Attachments not recommended or sold by the manufacturer may cause damage or injury.
- 5. Do not use outdoors.
- **6.** Do not immerse the electric cord, plug, or motor base in water or other liquid.
- 7. Do not operate with a damaged cord/plug; after the appliance malfunctions; or if it has been dropped or damaged in any manner.
- Return appliance to the nearest authorized service facility for examination, repair, or electrical or mechanical adjustment.
- 9. Unplug from outlet when: not in use; before putting on or taking off parts; before cleaning.
- 10. Remove the plug by gripping the plug. Never pull or yank on the cord to unplug the unit.
- **11.** Plug cord into wall outlet first, then operate blender. To disconnect, take container off, then remove plug from wall outlet.
- **12.** This appliance has a polarized plug (one blade is wider than the other) and will only fit into a polarized outlet one way. If the plug does not fit properly in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not modify the plug in any way.
- **13.** Do not let cord hang over the edge of table or counter, or touch hot surfaces.
- **14.** Wait until motor stops completely before removing the plug from the electrical outlet and before disassembling.
- **15.** Do not operate unattended.
- 16. Blades are sharp. Handle carefully. To avoid injury, properly attach the cutting unit blades to the base.
- **17.** Do not blend boiling or hot liquids over 104°F in the containers.
- **18.** Only use the appliance for its intended purpose.
- **19.** Do not operate while driving a vehicle.
- 20. Always use on a level, sturdy surface.
- 21. Wash container when finished with food preparation/consumption for easier cleaning.
- **22.** Store the blender containers with either the lid or the blade. Make sure the parts are thoroughly dry.
- 23. Cups are dishwasher-safe. Wash blades and lids in warm water with a mild detergent.
- **24.** In continuous operation mode, always allow the machine to rest for at least 30 seconds between consecutive blending cycles of one minute. Do not exceed three consecutive cycles.

SAVE THESE INSTRUCTIONS

SAFETY PRECAUTIONS

Do not disconnect the power plug from the electrical outlet with wet hands.	Do not operate Apollo Personal Blender on an unstable surface.
Do not assemble or disassemble while the power cord is plugged in.	Do not keep the Apollo Personal Blender where children can reach it.
Do not put any articles such as spoons, knives or forks into the Blender or Grinder container while operating the machine.	Do not hold blade directly with hands.

PARTS DESCRIPTION



1 Motor Base (250 watts)



1 Blender Blade for wet ingredients (4-pronged)



1 Grinder Blade for dry ingredients (2-pronged)



2 Blender Containers (2-cup size)



2 Grinder Containers (1-cup size)



4 Container Lids

Other Optional Parts & Accessories:



Carrying Cases

- 1. Black 8.5"W x 7.5"D x 7.25"H
- 2. Small(Silver) 9"W x 7.5"D x 6.5"H 3. Green 10.5"W x 8.5"D x 8.25"H

Silicone Spatula



Cutting Board

OPERATION GUIDELINES

- **1.** Plug the power cord into desired outlet.
- **2.** Fill the container with desired ingredients. When blending wet ingredients, use the following quidelines:
 - •Blending Container: at least 1/4 cup liquid for any recipe up to 1 1/4 cups maximum liquid.
 - Grinding Container: at least 1/4 cup liquid for any recipe up to 2/3 cup maximum liquid.
- **3.** Screw the appropriate blade onto the container, invert and place into Motor Base. *Hint:* For wet ingredients use the Blending Blade (4-pronged) and for dry ingredients, use the Grinding Blade (2-pronged)
- 4. Turn Blender/Grinder to fit into small notch (groove), once in place, press down. For pulse mode press down and release. For continuous mode press down and turn Blender/Grinder to the right (clockwise) until it locks into place.
- **5.** When in continuous mode, the machine will stay on until you press down, turn counterclockwise, and release the container. This stops the Blending/Grinding.
- **6.** Lift the container and turn it right side up. Unscrew the blade. Pour contents into appropriate serving container, or drink out of the cup.
- **7.** Rinse parts and store for next use.
- **8.** Your Apollo Personal Blender has a Thermo-Protection device that shuts it off automatically if the motor overheats. If this happens, unplug the unit and wait for 20 minutes before restarting the operation.

CLEANING AND STORAGE

Keep your appliance ready for use on the kitchen counter.

When it is not being used, leave it unplugged.

Store blades in a convenient, safe place, out of children's reach as you would with sharp knives.

The blending and grinding containers are dishwasher-safe (water temperature should not exceed 104°F). Blades and lids should be hand-washed with warm water and a mild detergent. To simplify cleaning, rinse blending/grinding containers and blades immediately after each use so food does not dry on them.

Be careful when washing the blades by hand. Avoid leaving them in soapy water, where they may disappear from sight.

The Blending/Grinding Container is made of Polycarbonate, which is a high impactresistant plastic. Its smooth surface will look new for years when properly maintained. Keep a sponge handy as you work and wipe spills from the base. Do not use abrasive cleaners on the base.

The rubber feet on the bottom of the motor base will keep the blender from moving on most work surfaces when the machine is processing heavy loads. Clean the rubber feet regularly. When the rubber feet are dirty, the machine can move on the counter. If feet leave spots on the counter, spray the counter with spot remover and wipe with a damp sponge. Repeat if necessary.

WARRANTY

We warrant to you, the end-user customer who has properly registered after purchasing the Apollo Personal Blender for a valuable consideration, that the parts and motor will be free from defects in materials and workmanship for a period of (1) year from the date of purchase. Warranty does not cover normal wear and tear.

In order for you to receive the benefits of this warranty, you are required to complete and mail the warranty registration card, containing all the requested information, to us within ten (10) days following the purchase of your Apollo Personal Blender.

- 1. No warranty will be provided until after we have actually received the enclosed warranty registration card, containing all the requested information, within ten (10) days of the date of original purchase. The warranty is valid only for the original purchaser. This warranty is non-transferable.
- 2. If the Apollo Personal Blender exhibits defects while in normal household use, we will, upon our actual receipt of a written notice of such defects from you during the warranty period, at our option, either repair or replace the Apollo which proves to be defective. However, we have no such obligation to repair or replace until after you have, by insured mail and in protective packaging, delivered the Apollo to the location of your service center as set forth. A replacement Apollo may be either new or like-new. Apollo may contain re-manufactured or reconditioned parts, which are equivalent to new in performance or may have been subject to incidental use.
- **3.** We do not warrant that the operation of the Apollo will be uninterrupted or error-free. In no event shall our liability exceed the retail value of the Apollo.
- 4. All warranty and repair services must be performed at a warranty service center, which is located within the country where the machine was originally purchased. However, in the event that: [i] the machine must be serviced at a service center, which is not located within the country where the machine was purchased; or [ii] there is no service center within the country where the machine is located and must be shipped to a service center in another country, then those service centers are responsible for the parts and service only, and any and all costs relating to the shipping, delivery and handling of the machine to and from those service centers shall be the sole responsibility of the owner.

This warranty does not cover defects resulting from: [a] failure to operate the Apollo in accordance with the instructions; [b] use of parts or supplies not provided or authorized by us; [c] negligent, improper or inadequate maintenance; [d] service performed or attempted by an unauthorized service person; [e] damages, accidental or otherwise, to the Apollo, which are not directly caused by us or the manufacturer; or [f] damages resulting from abuse, tampering, misuse, commercial use, or unauthorized modification of the Apollo.

WE MAKE NO OTHER EXPRESS OR IMPLIED WARRANTY OR CONDITION WHETHER WRITTEN OR ORAL TO THE EXTENT ALLOWED BY LOCAL LAW, ANY IMPLIED WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE OR IMPLIED WARRANTY OR CONDITION OF MERCHANTABILITY IS LIMITED TO TWO (2) YEARS. In the event that such limitation or exclusion on the duration of an implied warranty is not allowed in the state or county wherein you reside, the above limitation or exclusion will not apply. This warranty gives you specific legal rights and protection, and you might also have other rights that vary from state to state, or country to country.

TO THE EXTENT ALLOWED BY LOCAL LAW, THE REMEDIES IN THIS WARRANTY STATE-MENT ARE YOUR SOLE AND EXCLUSIVE REMEDIES. EXCEPT AS INDICATED ABOVE, IN NO EVENT WILL WE BE LIABLE FOR DIRECT, SPECIAL, INCIDENTAL, CONSEQUENTIAL (INCLUDING LOST PROFIT, OR OTHER DAMAGE, WHETHER BASED IN CONTRACT, TORT, OR OTHERWISE). Some states or counties may not allow the exclusion or limitation of incidental or consequential damages. If you reside in such a state or county, the above limitation or exclusion may not be applicable.

In the event that you have any questions concerning the use and care for this product or concerning service, please write a letter or send an e-mail to the following address explaining the nature of your concern, or call us at 888-618-2078.

P.O. Box 4089, Cerritos, CA 9 www.tribest.com (e-mail) ser		
model#	serial#	date warranty mailed

BASIC INFORMATION/SPECIAL FEATURES

Apollo Personal Blender has several special features, including:

- 1. Simple to use and easy to clean up.
- 2. Very portable and lightweight (under 3 pounds).
- **3.** Efficient and guick food preparation; recipes can be completed in less than one minute.
- Convenient to use anywhere you go: at home, at work, on business trips, or on vacation.
- **5.** Use on the road: in your car, camper, RV, or boat with inverter (optional part).
- **6.** So very versatile-prepare many delicious recipes: from smoothies to soups, from pesto to puddings and more in less than 30 seconds.
- **7.** 2 modes of operation: Pulse Blending/Grinding & Continuous Blending/Grinding.
- **8.** Multifunctional: use to grind nuts, seeds or even fresh coffee beans (with the grinder blade and container)
- **9.** Compact and powerful 250 watts of blending and grinding power.
- Healthy food preparation use whole fresh foods to make a wide variety of easy to swallow dishes.
- **11.** Quick and easy baby food preparation from fresh and wholesome foods to nourish and feed growing children.

PRODUCT STANDARD

ITEM	FOOD PROCESSOR
METHOD	BLENDER / GRINDER
MODEL	AP-200
VOLTAGE	AC 120V (USA/Canada Models) or AC 230V (Europe/Asia Models)
FREQUENCY	60Hz
ELECTRIC POWER	250W
CONTAINER SIZE	Blending Container: 2 cups Grinding Container: 1 cup
PRODUCT SIZE	124mm x 124mm x 312mm (4.89in x 4.89in x 12.29in) 124mm x 124mm x 250mm (4.89in x 4.89in x 9.85in)
WEIGHT	1.2Kg (2.651 lbs)



TRIBEST CORPORATION
P.O. Box 4089, Cerritos, CA 90703
(tel) 714-871-7150
www.tribest.com
(email)service@tribest.com

